Bosch Dishwashers Step-Up Guide

Find a complete dishwasher assortment on Lowes.com/Bosch



А А А ...

Standard Third Rack 44 ADA & 18" options available



Touch Control 4) 42 m/ ADA & 18" options available

Getting the job done.

Clean30 cycle Clean dishes in 30 minutes or less. Cleans lightly soiled dishes quickly, like glasses and silverware, so you can reuse them at the same event.

Enjoy your next dinner party even

more knowing our Speed60® cycle can have your glasses and dishes clean and dry in about 60 minutes.







MyWay™ Rack

39

make the dishes very hot. The stainless steel tub of the dishwasher cools faster than your dishes because stainless steel cools faster than glass and porcelain.

Here's how it works:

 Condensation occurs when the moist air in the dishwasher comes into contact with the cooler stainless steel tub, and turns into water droplets These water droplets trickle down to the bottom of the dishwasher and are drained.

· The final rinse uses high-temperature water to

Perceivable quality-

What is condensation drying?

Ultimate drying performance

All Bosch dishwashers use a condensation drying process. Instead

condensation drying involves a number of dishwashing elements

that work together to efficiently dry your dishes more hygienically

of utilizing a heating element at the bottom of a dishwasher,

than conventional air drying; and with minimal energy.

Benefits:

· Since it's a closed system with no fan, the cleaning process is more sanitary.

• With no exposed heating element, plastic utensils and dishes placed on lower rack will not melt.

For best results:

- Always use a liquid rinse aid.
- · Select the Auto cycle.
- · Press the Sanitize or Extra Dry option.

Bosch Home Appliances

1.800.944.2904 To view all Bosch appliance categories, visit: www.Lowes.com/Bosch

©2017 BSH Home Appliances Corporation. All rights reserved. Bosch is a registered trademark of Robert Bosch GmbH. All information presented herein is based on data available at the time of printing and is subject to change without notice.






Bosch Mainline Dishwashers



© 2017 Lowe's Companies, Inc. All rights reserved. Lowe's, the gable design, and Never Stop Improving are trademarks of LF, LLC. All are used with permission.

Maximize loading space without sacrificing it elsewhere.

Simple solutions only Bosch can provide.



With the industry's largest 3rd rack loading capacity,¹ MyWay[™] frees up more room in the bottom rack for larger items like pots. colanders and baking sheets.







RackMatic[®] adjustable rack

This remarkable middle rack easily raises or lowers in just one step, even when full. Designed to allow taller items like stemware to fit in the middle rack while leaving room for pots and pans below, it offers three different heights and up to nine separate rack positions.



FlexSpace[™] tines

Standard 3rd rack

models

Flexible 3rd rack

MyWay[™] rack

Provides the perfect space for flatware,

large utensils, measuring cups, or

nearly anything else that's difficult to

fit in a traditional dishwasher, while its

V shape leaves room below both sides

middle rack. Available on all 300 Series

for taller items like stemware in the

Expandable wings easily lower to

accommodate more of your deeper items, while adjustable tines let you

customize the rack's loading space to

fit awkward or bulky utensils. Available

on all 500 and 800 Series models.

MvWav[™] offers more room for more

kinds of items in the top rack, such as

cereal bowls, whisks, tongs and large measuring cups, creating more freedom

in loading below. Available on all 800

Series Premium models

This convenient new feature lets you fold back every other tine in one simple step, so it's easier to fit your largest, bulkiest items. Available on lower racks in 300 Series models and up, it helps to hold pots and pans upright, leaving more room for your other dishes.


Advancing the science of silence.

To a Bosch engineer, quiet operation is just as important as sparkling clean dishes. For you, that means never having to wait until going to bed to run the dishwasher. And when hosting a dinner party, you can start the dishes right after dinner, instead of waiting until everyone leaves. Because life doesn't have to stop just because your dishes need to be cleaned.

The Quietest dishwasher brand in the U.S.¹

With models as low as 39 dBA. Bosch is the guietest dishwasher brand in the U.S.¹ To reach these new heights of silence, Bosch engineers approached noise reduction from every angle, incorporating 18 unique sound-reducing technologies

Understanding decibel levels



¹Based on an average of sound ratings for 24" full-size stainless steel tub dishwashers contained in major brands' websites. Major brands defined as TraQline Top 5 Market Share, June 2016









Rack-mounted detergent tray

Optimized for tablets, our detergent tray holds tabs in place for a dedicated spray jet to directly dissolve them completely. This not only results in a deeper clean, it also helps to reduce unwanted noise since there's no water jet spraving the inner door. (Dishwasher also works with powder and gel.)





Sensor wash system

This state-of-the-art system uses an advanced scanning-eye sensor to literally look at the level of soil in the wash water, and adjusts both the water temperature and length of the wash cycle to eliminate redeposits. It can also determine if a secondary, fresh water fill is necessary, deleting the cycle whenever appropriate to save water and energy.

EasyGlide[™] rack system

For a level of quality you can both touch and feel, we've incorporated smooth-rolling ball bearings to our rack wheels. The result is a smoother glide that opens effortlessly-even with a fully loaded rack-for a more premium feel with every pull.

The easy way to deal with hard water.

Hard water is tough on dishes-and your dishwasher. If you live in a hard water area, glasses may come out looking cloudy or spotted, and your dishes may not get as clean as they should. That's why select 300 Series and ADA dishwashers offer a built-in water softener, which removes hard water spots caused by lime deposits and softens the water to appropriate levels for spot-free, shiny dishes.



Hard water deposits



After softening the water