

Energizer®

**FIND YOUR
SPECIALTY BATTERY**

1 FIND THE
DIAMETER
OF YOUR
BATTERY


2 FIND THE
DEPTH
OF YOUR
BATTERY

3 PLACE YOUR
CURRENT BATTERY
ON TOP TO FIND
A REPLACEMENT MATCH

When viewing online use this scale to zoom in. Once your quarter fits the size of this quarter, stop zooming to best match the size of your battery.



Print this page at **100%** size using the NO SCALING setting



LITHIUM MINIATURE



REPLACES

123

EL123, 5018LC,
CR123, CR123A,
CR17345



REPLACES

1CR2

5046LC, CR15H270,
CR17355, DLCR2,
EL1CR2, KCR2, RLCR2-2



REPLACES

CRV3

5047LC, CR-V3, ELCRV3



REPLACES

2CR5

2CR5M, 5032LC, DL245,
EL2CR5, RL2CR5,
RL2CR5



REPLACES

223

223A, 5024LC,
CR-P2, CRP2,
DL223, EL223



WATCH/ELECTRONIC



REPLACES

AAAA

E98, LR8D425,
MN2500, MX2500



REPLACES

E90/N

4001, 810, 910A,
AMS, LRI,
MN9100, UM-5



REPLACES

A23

1181A, A23BP, G27A,
DL23, MN-21B, MN21,
V23GA



REPLACES

A27

27A, A27BP, G27A,
GP27A, L82B,
MN27



REPLACES

A544

478A, 4LR44, GP47B,
K28L, L1325, PX28A,
V28PX

Energizer®

FIND YOUR SPECIALTY BATTERY

1 FIND THE DIAMETER OF YOUR BATTERY


2 FIND THE DEPTH OF YOUR BATTERY

3 PLACE YOUR CURRENT BATTERY ON TOP TO FIND A REPLACEMENT MATCH

When viewing online use this scale to zoom in. Once your quarter fits the size of this quarter, stop zooming to best match the size of your battery.



Print this page at **100%** size using the NO SCALING setting



LITHIUM SPECIALTY



REPLACES

CR2450
5029LC, DL2450,
ECR2450

3 VOLTS



REPLACES

CR2430
2011LC, DL2430,
ECR2430

3 VOLTS



REPLACES

CR2032
5004LC, BR2032,
DL2032, ECR2032,
ST-T15

3 VOLTS



REPLACES

CR2025
280-205, 5003LC,
BR2025, DL2025,
ECR2025, SB-T14

3 VOLTS



REPLACES

CR2016
280-202, 280-204,
280-206, 5000LC, BR2016,
DL2016, SB-T11, ECR2016

3 VOLTS



REPLACES

CR1632
BR1632, DL1632, ECR1632,
KCR1632, KECR1632,
KL1632, LI632

3 VOLTS



REPLACES

CR1620
280-208, BR1620,
DL1620, ECR1620

3 VOLTS



REPLACES

CR1616
BR1616, DL1616,
ECR1616

3 VOLTS



REPLACES

CR1225
LO9, DL1225, CR1225

3 VOLTS



REPLACES

CR1220
BR1220, DL1220,
ECR1220, SB-T13

3 VOLTS



REPLACES

CR1216
BR1216, DL1216B,
ECR1216BP

3 VOLTS

WATCH/ELECTRONIC



REPLACES

2L76
5008L, CR1108,
CR1/3N, DL1/3N,
KL-13N

2L76



REPLACES

A76
157, 303, 357, AG13,
EPX76, LR44, S76,
SG13, SR44

A76



REPLACES

357/303
280-03, 280-08,
D303/357, SB-A9, SR
1154 SW, SR 44 SW, SR
44SW, SR44SW, WS14

357/303



REPLACES

390/389
101122, 280-15,
D389/390, SB-BU,
SR130W, SR54

390/389



REPLACES

395/399
280-20, 280-48,
D395/399, SB-AP,
SB-OP, SR57, SR927SW,
TR927SW

395/399



REPLACES

371/370
280-31, 371BP,
D370/371, SB-AN,
SR69, SR920W,
TR920SW

371/370



REPLACES

392/384
101125, 280-11, 280-13,
D384/392, SB-B1,
SR41, SR41W, SR736W,
TR41W4

392/384



REPLACES

377/376
377BP, D377,
SB-AW, SR626SW,
SR66

377/376



REPLACES

364/363
SR60, SR621SW,
280-34, D364,
SB-AG, SB-DG,
TR621SW

364/363



REPLACES

379
280-59, D379,
SB-AG, SB-DC,
SR521SW, SR63

379